



AO1 Practice Course

May 4, 2023

Astronomical Observation and Practice 1

Who am I



Name Bumhoo Lim (임범후) (통합 2022 Spring)

Team Solar System Research Team (Prof. Ishiguro)

Office 19-309

E-mail bumhoo7@snu.ac.kr

Phone 010-3374-3963

Please feel free to contact me anytime if you have any questions!



What We Do in TA Session

5 / 4 (Thu)

1. Setup (Most important & time consuming...)
2. Pre-processing (*0-preprocessing.ipynb*)
3. FITS file handling (*1-fits-basic.ipynb*)
4. Query (*5-query.ipynb*)

5 / 9 (Tue)

1. Aperture Photometry (*2-center, 3-aperture, 4-annulus.ipynb*)
2. Differential Photometry (*6-diffphot.ipynb*)

What we don't do: PSF photometry, Surface photometry



Reference

This TA session largely based on the [SNU AO Class Python Notes](#) produced by previous TA of this class (Yoonsoo P. Bach; [github](#))

You can download full materials (SNU_AOpython) from [here](#) OR

\$ (move to your directory)

\$ git clone https://github.com/ysBach/SNU_AOpython.git

Also you can find previous repository (SNU_AOclass) from [here](#) OR

\$ (move to your directory)

\$ git clone https://github.com/ysBach/SNU_AOclass.git

We are not gonna learn about git & github (due to the time limit)

File Setup



1. Make your own directory

```
$ mkdir AO1_BumhooLIM      # make directory
$ cd AO1_BumhooLIM         # change current directory
```

- You are gonna use this directory for the whole practice.
- This directory **will be deleted** after the semester. So please make sure to back up your files if you need.

example of basic commands

```
$ rmdir # remove empty directory
```

```
$ . current directory
```

```
$ .. parent directory
```

```
$ ~ home directory
```

- If you need other basic UNIX commands, refer [here](#).

File Setup



2. Download your own data from the SAO NAS homepage

- <https://sao.snu.ac.kr/>
 - You may need ID & PW (TA will notify to you)
 - File Station > IMSNG > date(e.g. 2023-04-27) > choose files > *download in .zip*
 - You need to download at least
 - 1) bias (*calibration-*bias.fit*)
 - 2) dark (*calibration-*dk*.fit*)
 - 3) flat (with your filter) (*Flat-*(UBVRI).fit*)
 - 4) target raw data (*[target]-*(UBVRI).fit*)
 - You can unzip the .zip file with
`$ unzip [filename].zip`


(tip) Most of the files will be downloaded to *home/Downloads* folder. You can move the files with
`$ mv ~/Downloads/[filename] . (current directory)`

File Setup



3. Download tutorial data [here](#). (*Tutorial_Data.zip*)

4. Download Python scripts from eTL module.

- These scripts are basically same with [SNU AO1 Python Notes](#) made by Yoonsoo P. Bach.
 - We are going to utilize this lecture note in our practice.
 - Due to the time limit, we are not gonna treat all the sections in this note. **But I highly recommend you to read and execute all the sections in this lecture note.**
- 

Software Setup



1. Anaconda

Anaconda is open-source Python distribution platform to perform Python/R data science.

- 1) Download the latest version of Anaconda installer from [here](#).
- 2) Install Anaconda3
`$ bash Anaconda3-[latest version].sh` # if Anaconda3 already exists, add option -u (update)
- 3) Execute conda
`$ conda activate` # In case of Windows, you can open 'Anaconda Prompt' by searching.
If this command not working, try `$ source ~/anaconda3/etc/profile.d/conda.sh` and retry.
- 4) (**Important**) Setup your virtual environment referring to the instruction [here](#).
- 5) Activate your environment and open *Jupyter Notebook* (One of the Python interpreters)
`$ conda activate snuao` # when you open the conda next time
`$ jupyter notebook &`

Jupyter Notebook



When you close
Jupyter Notebook
Window

Quit

Logout

Files

Running

Clusters

Select items to perform actions on them.

Upload

New





0 / DATA / TA / 2022A / Class1				Name	Last Modified	File size
..					seconds ago	
NGC3367					2 days ago	
Preprocess.ipynb					2 days ago	572 kB
Untitled.ipynb					a day ago	572 kB

Jupyter Notebook file
(*ipynb)

































When you create new
Jupyter Notebook file
[New] – [Python 2/3]

Jupyter Notebook



jupyter Preprocess (autosaved)  Logout

File Edit View Insert Cell **Reset** **Run All Cells** Not Trusted Python 3

Save

1. Inspecting the Data

Python code cell (input)

```
In [4]: current_dir = os.path.abspath(".")
raw_dir = current_dir+"/NGC3367/0 raw/"
bias_list = sorted(glob.glob(raw_dir+"cal*bias.fit"))
dark_list = sorted(glob.glob(raw_dir+"cal*dk*.fit"))
flat_list = sorted(glob.glob(raw_dir+"skyflat*.fit"))
sci_list = sorted(glob.glob(raw_dir+"NGC3367*.fit"))
print(f"Bias: {len(bias_list):d} frames")
print(f"Dark: {len(dark_list):d} frames")
print(f"Flat (sky): {len(flat_list):d} frames")
print(f"Science (object): {len(sci_list):d} frames")
```

Shift + Enter
(to run each cell)

Bias: 9 frames
Dark: 27 frames
Flat (sky): 7 frames
Science (object): 6 frames

Return printing (output)

Software Setup



2. SAO DS9

DS9 is very useful fits file display and visualization tool.

- 1) You can install ds9 with
\$ sudo apt-get update
\$ sudo apt-get -y install saods9
- 2) After installation, test with
\$ ds9 &
- 3) You can open your fits file using
\$ ds9 [*filename*].fits &

Software Setup



3. Slack

- Basically “chatting app” like kakaotalk
- I will invite you to the 2023-AO1 (excluded) channel via your email.
You can ask about your projects, group works, and Python code.
- *I will expire the channel after the end of the semester.*



If you are not familiar with Python...




- There are numerous materials related to the Python programming language, including Yoonsoo's lecture note. ([here](#))
- I'm not gonna explain the very basic grammar of Python due to the time limit. However, **I'll explain in detail as possible each line's purpose, function, and related grammar.**





We will utilize Tutorial_Data in this practice course. If you want to adopt your data in this practice similar with tutorial data, you should prepare two things.

1. pre-processing (bias, dark, flat)
2. Insert WCS to fits file (to do query)



Pre-processing (*0_Preprocessing.ipynb*)

1. Bias

- Measuring **zero noise level** of instrument
- No exposure to light (exposure time = 0 sec)
- Exist in all kinds of data (dark, flat, raw)




2. Dark

- Measuring **thermal noise (dark current)** in the instrument
- Pixel values proportional to exposure time
- Exist in flat & raw data

3. Flat

- To correct for pixel-to-pixel variations of instrument response
- Varying with wavelength (U, B, V, R, I...)
- Dome flat, twilight flat, etc.

Pre-processing (*0_Preprocessing.ipynb*)



WCS setup



To do query from the sky catalog (*5_Querying_from_the_Catalog.ipynb*), we should insert WCS (World Coordinate System) to the fits file.

- Upload your fits file to [astronomy.net](https://www.astronomy.net)
 - Advanced Settings
 - Scale → custom, Units → “arcseconds per pixel”, Lower bound: 0.3, Upper bound: 0.4
 - CRPIX center: check
- Click upload
- After a success, go to result page and download the new FITS file (*new-image.fits*)
- Check it with DS9 (Analysis → Catalogs → Optical → *URAT1(or other catalog)*)
- If you have too many FITS files to upload, you may try the offline version of the astronomy.net in [here](#). It is only available for Linux or Mac (or virtual Linux in Window).